

# SuperPole™ Floor Receptacle System (F.R.S)

A portable assist pole that installs into a floor receptacle in a concrete floor. Best suited for institutions where room needs change frequently. Pole installs and removes from receptacle in seconds.

## Features and Benefits

- **Floor Receptacle.** Installed in concrete, flush with floor surface to reduce trip hazards. When not in use, receptacle is sealed with a liquid tight cap.
- **Cap Removal / Storage.** Receptacle cap is unscrewed using pins located on the bottom of the pole. Prevent loss by storing the cap inside the top of the pole.
- **Installation.** Simply insert the pole into the receptacle and lock in place by turning the knob on top of the pole. Pole is secure and ready to use.



RECEPTACLE



UNSCREW CAP



CAP REMOVAL / STORAGE



INSERT POLE



SECURE POLE

## Technical Specifications:

F.R.S. Pole	Pole Diameter: 1.5"/3.81cm. Latex free grip. Pole Length: 57"/145cm. 53.25"/135cm (when installed).																		
Receptacle	Receptacle Diameter: 1.875"/4.8cm. Receptacle Length: 3.9375"/10cm.																		
Weight Capacity	350 lbs / 159 kgs.																		
Assistance Level	<table border="1"> <thead> <tr> <th>M</th> <th colspan="4">ASSISTANCE LEVEL</th> <th>M</th> </tr> </thead> <tbody> <tr> <td>I</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>A</td> </tr> <tr> <td>N</td> <td></td> <td></td> <td></td> <td></td> <td>X</td> </tr> </tbody> </table>	M	ASSISTANCE LEVEL				M	I	1	2	3	4	A	N					X
M	ASSISTANCE LEVEL				M														
I	1	2	3	4	A														
N					X														