

# Running Board Lifts



## Startracks Power Running Board Lifts

Our patented powered running board lifts were developed to assist individuals who can at least stand to enter a vehicle such as pickups, SUV's, and vans. The running board, which is 10 inches deep, is custom fabricated for each vehicle. Custom installation required for each vehicle is also required. Vehicle color matching is also offered as an option when purchasing the running board. The running board is powered by a 12 volt motor hydraulic actuator system which is located under the vehicle, via wireless remote. This lift, which is attached to the frame of the vehicle, can be installed on either side or both sides to suit the needs of the customer. The running board lift is designed to allow the user to move the lift in a "up and down" motion at any time by triggering the remote. The installation also features a hard wired back-up switch with an automatic stop when the running board has reached the up position. If you have not brought the running board completely up, as soon as the transmission is moved out of the park position, the lift will automatically rise and shut off in the "up" position.



 *Startracks Custom Lifts*

Elkhart, Indiana • (574) 596-5331 • [sales@startracks.org](mailto:sales@startracks.org)